

Update Date : 2019-06-13 Print Date : 2020-02-27

BR02-52

SERVICE BRAKE

## SPRING BRAKE CONTROL VALVE (TYPE-A)


### DATA AND SPECIFICATIONS

EN0680202100010

Type	Variable pressure control type
Outlet pressure difference between parking and releasing stroke at a specified lever angle	Within 147 kPa {1.5 kgf/cm <sup>2</sup> , 21.32 lbf/in. <sup>2</sup> }

### DESCRIPTION

EN0680202C100012




SHTS068020200111

1 Body cover	11 Handle return spring (If so equipped)
2 Feed valve spring	12 Pull rod
3 Piston	13 Knob
4 Feed valve	14 Compression spring
5 Valve seat	15 Release knob
6 Valve body	16 Handle body
7 Piston spring	A Inlet
8 Valve spring	B Outlet
9 Cam	C Exhaust (PARK)
10 Cam holder	

### COMPONENT LOCATOR

EN0680202D100010



SHTS068020200112

1 Body cover	9 Valve seat	16 Pull rod
2 Shim	10 Valve seat spring	17 Knob sub assembly
3 Piston spring	11 Handle return spring (if so equipped)	18 Cam holder
4 Feed valve spring	12 Valve body	19 Body pin
5 Retainer ring	13 Handle body	20 Cam holder pin
6 O-ring	14 Stopper	21 Cam
7 Piston	15 Compression spring	22 Piston guide
8 Feed valve		


**Tightening torque**

**Unit: N·m {kgf·cm, lbf·ft}**

A 5.4-7.4 {55-75, 4.0-5.4}	B 3.4-4.9 {35-50, 2.6-3.6}
----------------------------	----------------------------

## OVERHAUL

EN0680202H200009




SHTS068020200113

### IMPORTANT POINTS - ASSEMBLY

#### 1. LUBRICATION

- (1) When assembling the spring brake control valve, replace the feed valve, valve seats and O-rings.
- (2) Apply silicone grease to each sliding surface of the assembly parts, O-rings and O-ring grooves.


- a. O-ring
- b. Feed valve
- c. Piston
- d. Valve seat
- e. Cam
- f. Cam holder



SHTS068020200114

#### 2. ASSEMBLE THE CAM ASSEMBLY.

- (1) When assembling the cam and cam holder, make sure that the cam holder pin and spiral groove of the cam are aligned.
- (2) When installing the cam assembly to the valve body, the valve body pin and straight groove of the cam must be aligned.




SHTS068020200115

- (3) Adjust dimension "A" with the shim.

**Assembly standard: 33.8-34.2 mm {1.331-1.346 in.}**


- a. Cam
- b. Cam holder
- c. Shim



SHTS068020200116

#### 3. SPRING BRAKE CONTROL VALVE PERFORMANCE TEST

- (1) First, connect the pressure gauge to the outlet line and apply an air pressure of 980 kPa {10.0 kgf/cm<sup>2</sup>, 142 lbf/in.<sup>2</sup>} to the inlet line.



- (2) Move the spring brake control lever towards the OFF position, gradually and confirm that the air pressure in the outlet line meets the characteristic shown in figure.

**Standard:**

**Handle angle: Outlet pressure: kPa {kgf/cm<sup>2</sup>, lbf/in.<sup>2</sup>}**


**15° 275 {2.8, 39.9}**

**35° 441.6-500.4 {4.5-5.1, 64.0-72.6}**

**Over 42° 980 {10.0, 142}**

**NOTICE**

**The characteristic shown is under the inlet pressure of 980 kPa {10.0 kgf/cm<sup>2</sup>, 142 lbf/in.<sup>2</sup>.}**



- (3) Confirm the following functions.

- a. The control handle is locked at PARK position.
- b. The control handle automatically turn to OFF position when the lever is released at PARK position.






BR02-56

SERVICE BRAKE

## INSPECTION AND REPAIR

EN0680202H300014

Unit: mm {in.}

Inspection Item	Standard	Limit	Remedy	Inspection Procedure
<b>Piston and valve body:</b> Wear and damage	—	—	Replace, if necessary.	Visual check  
<b>Cam, pin and cam holder:</b> Wear and damage	—	—	Replace, if necessary.	Visual check  
<b>Piston spring, valve spring and handle return spring:</b> Free length/ Setting length/ Setting load Crack, rust and damage	<b>Piston spring</b> 27.9 {1.10}/ 25.0 {0.98}/ 553.1 N {56.4 kgf, 124.34 lbf}	500.1 N {51.0 kgf, 112.43 lbf} (Setting load)	Replace, if necessary.	Measure and visual check    VALVE SPRING   PISTON SPRING HANDLE RETURN SPRING  
	<b>Valve spring</b> 19.6 {0.77}/ 10.5 {0.41}/ 19.6 N {2.0 kgf, 4.41 lbf}			
	<b>Handle return spring</b> 19.3 {0.76}/ 13.5 {0.53}/ 7.8 N {0.8 kgf, 1.76 lbf}	6.9 N {0.7 kgf, 1.55 lbf} (Setting load)		
<b>Feed valve spring:</b> Rust and damage	—	—	Replace, if necessary.	Visual check  